



Mittels den rückseitigen Drehschaltern wird bestimmt welche DALI Gruppe und welche DALI Szenen vom Tastdimmer angesteuert bzw. hinterlegt werden.

Stellt man bei Group den Drehschalter auf Position „0“ ein, so werden die Befehle Broadcast versendet. Bei Position „1“ bis „15“ werden die Gruppen 0-14 angesprochen. Die 16. DALI Gruppe die mit 15 bezeichnet wird, kann mit diesem Tastdimmer nicht angesteuert werden.

Stellt man bei Scene den Drehschalter auf Position „0“ ein, so werden die 2 möglichen Szenen (S1 & S2) in den DALI Aktoren unter Szene 0 und 1 abgespeichert. Stellt man den Drehschalter z.B. auf Position „7“ ein, so werden die Szenen 7 und 8 belegt und bei Position „15“ die Szenen 15 und 0.

The rear rotary switches are used to determine which DALI group and which DALI scenes are controlled or stored by the push button dimmer.

If you set the rotary switch to position "0" at Group, the commands Broadcast are sent. With position "1" to "15" groups 0-14 are addressed. The 16th DALI group, which is designated 15, can not be controlled with this push button dimmer.

If you set the rotary switch to position "0" for Scene, the 2 possible scenes (S1 & S2) are stored in the DALI actuators under scene 0 and 1. If you set the rotary switch, e.g. at position "7", scenes 7 and 8 are occupied and at position "15" scenes 15 and 0 are occupied.